


DESCRIPTION



- | | | | | | |
|----|-----------------------------|----|-------------------------|----|------------------------|
| 1 | Converter housing | 13 | One-way clutch | 19 | Oil distributor |
| 2 | Torque converter | 14 | Low & reverse clutch | 20 | Control valve assembly |
| 3 | Oil pump assembly | 15 | Transmission case | 21 | Oil pan |
| 4 | O.D. planetary gear | 16 | Governor valve assembly | 22 | O.D. band brake |
| 5 | Direct clutch | 17 | Rear extension | 23 | O.D. case |
| 6 | Drum support | 18 | Output shaft | 24 | Input shaft |
| 7 | Intermediate shaft | | | | |
| 8 | 2nd band brake | | | | |
| 9 | High-reverse clutch (Front) | | | | |
| 10 | Forward clutch (Rear) | | | | |
| 11 | Front planetary gear | | | | |
| 12 | Rear planetary gear | | | | |

GENERAL SERVICE NOTICE

Repair Notes

- Before proceeding with disassembly, thoroughly clean the outside of the transmission. It is important to prevent the internal parts of the transmission from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use a nylon cloth or paper towel for wiping parts clean. Common shop rags can leave lint that might interfere with the transmission's operation.
- When disassembling parts, be sure to place them in order in parts rack so they can be put back in the unit in their proper positions.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals, and O-rings should be replaced. It is also very important to perform functional tests whenever it is designated.
- The valve body contains many precision parts

and requires extreme care when parts are removed and serviced. Place removed parts on a parts rack so they can be put back in the valve body in the same positions and sequences. Care will also prevent springs and small parts from becoming scattered or lost.


- Before assembly, apply a coat of recommended A.T.F. to all parts. Vaseline may be applied to O-rings and seals. Do not use any grease.
- Care should be taken to avoid damaging O-rings, seals and gaskets when assembling.

Abbreviations used throughout this section stand for the following:

- A.T.F. Automatic transmission fluid
- D₁ Drive range 1st gear
- D₂ Drive range 2nd gear
- D₃ Drive range 3rd gear
- D₄ Drive range 4th gear
- O.D. Overdrive
- 1₂ 1 range 2nd gear
- 1₁ 1 range 1st gear

Control Valve

CONTROL VALVE UPPER BODY




SAT742

GENERAL SERVICE NOTICE


Control Valve (Cont'd)

CONTROL VALVE LOWER BODY



SAT7E

Lock-up Control Valve and O.D. Cancel Valve



SAT49E


GENERAL SERVICE NOTICE

Oil Channel

Oil channels which connect components are located in the areas shown below.


OIL CHANNELS IN OIL PUMP

Oil pump cover side



SAT499


Oil pump housing side



SAT500


OIL CHANNELS IN TRANSMISSION CASE

Front face side




SAT501

Lower face side



SAT502

OIL CHANNELS IN O.D. CASE




In regards to one-way plug, refer to page AT-32.

SAT645


GENERAL SERVICE NOTICE

Oil Channel (Cont'd)

OIL CHANNELS IN DRUM SUPPORT



OIL CHANNELS IN CONVERTER HOUSING



Mechanical Operation


In the L4N71B automatic transmission, each part operates as shown in the following table at each gear select position.

Range	Direct clutch	O.D. band servo		High-reverse clutch (Front)	Forward clutch (Rear)	Low & reverse brake	2nd band servo		One-way clutch	Parking pawl
		Apply	Release				Apply	Release		
Park	ON	(ON)	ON			ON				ON
Reverse	ON	(ON)	ON	ON		ON		ON		
Neutral	ON	(ON)	ON							
D	D ₁ (Low)	ON	(ON)	ON	ON				ON	
	D ₂ (Second)	ON	(ON)	ON	ON		ON			
	D ₃ (Top)	ON	(ON)	ON	ON	ON	(ON)	ON		
	D ₄ (O.D.)		ON		ON	ON	(ON)	ON		
2	Second	ON	(ON)	ON	ON		ON			
1	1 ₂ (Second)	ON	(ON)	ON	ON		ON			
	1 ₁ (Low)	ON	(ON)	ON	ON	ON			ON	

The low & reverse brake is applied in "1₁" range to prevent free wheeling when coasting and allows engine braking.

GENERAL SERVICE NOTICE

Hydraulic Control Circuits




SAT940

ON-VEHICLE SERVICE

Control Valve


1. Drain fluid by removing oil pan.
2. Remove kickdown solenoid and vacuum diaphragm & rod.

Be careful not to lose vacuum rod.




SAT506

3. Remove control valve assembly.



Be careful not to drop manual valve out of valve body.

4. Disassemble, inspect and assemble control valve assembly. Refer to Control Valve Body.
 5. Install control valve assembly.
- Set manual shaft at Neutral, then align manual plate with groove in manual valve of control valve assembly.
 - Securing bolts come in 3 different lengths.



- 1 40 mm (1.57 in)
- 2 35 mm (1.38 in)
- 3 25 mm (0.98 in)


- After installing control valve to transmission case, make sure that control lever can be moved to all positions.
6. Install kickdown solenoid and vacuum diaphragm & rod.

Make sure that vacuum diaphragm rod does not interfere with side plate of control valve.


ON-VEHICLE SERVICE

Extension Oil Seal Replacement

1. Remove oil seal.




2. Apply coat of A.T.F. to oil seal surface, then drive new seal into place.




3. Coat sealing lips with vaseline, then install propeller shaft.

Parking Component

1. Remove oil pan.
2. Remove propeller shaft.
3. Remove speedometer pinion.




4. Support transmission with a jack, then remove rear mounting bolts.



ON-VEHICLE SERVICE

Parking Component (Cont'd)


- Remove rear extension bolts, then draw out rear extension with rear mounting.



- Remove control valve assembly.
- Inspect and repair parking components. Check component parts for wear or damage.

Governor Valve Assembly

- Drain oil by removing oil pan.
- Remove rear extension with rear mounting.
- Remove governor valve assembly.




- Inspect and repair governor valve assembly. Refer to Governor for inspection.

Inhibitor Switch Adjustment

Disconnect harness at connector, then remove inhibitor switch.

- Check continuity at "N", "P" and "R" ranges.




ZIE ook SUPPLEMENT II
AT-2

SAT959

- With control lever held in "Neutral", turn manual lever an equal amount in both directions to see if current flow ranges are nearly the same. (Current normally begins to flow before manual lever reaches a angle of 1.5° in either direction.)
If current flows outside normal range, or if normal flow range is out of specifications, properly adjust inhibitor switch.

Adjust inhibitor switch as follows:

- Place the manual valve in Neutral (vertical position).
- Remove the screw.




SAT097

ON-VEHICLE SERVICE


Inhibitor Switch Adjustment (Cont'd)

Loosen the attaching bolts.
Using an aligning pin, [2.0 mm (0.079 in) dia.]
move the switch until the pin falls into the hole
in the rotor.



SAT098

Tighten the attaching bolts equally.
Recheck for continuity. If faulty, replace the
switch.




Manual Linkage Adjustment

Move the shift lever from the "P" range to "1"
range. You should be able to feel the detents in
each range.

If the detents cannot be felt or the pointer indicat-
ing the range is improperly aligned, the linkage
needs adjustment.


1. Place shift lever in "N" range.
2. Loosen locknuts.

*IE ook SUPPLEMENT II
AT-2*



Lock nut

3. Move range selector lever to the "N" range.



Range selector lever


SAT741

4. Tighten lock nuts when floor control lever is in
"N" range and pushed against the "P" range
side.
5. Move control lever from "P" range to "1"
range. Make sure that control lever can move
smoothly and without any sliding noise.

ON-VEHICLE SERVICE

Vacuum Diaphragm Rod Adjustment

1. Remove diaphragm from transmission case.
2. Using a depth gauge, measure depth "L". Be sure vacuum throttle valve is pushed into valve body as far as possible.
3. Check "L" depth with chart below and select proper length rod.




SAT078

Vacuum diaphragm rod selection

Measured depth "L" mm (in)	Rod length mm (in)	Part number
Under 25.55 (1.0059)	29.0 (1.142)	31932 - X0103
25.65 - 26.05 (1.0098 - 1.0256)	29.5 (1.161)	31932 - X0104
26.15 - 26.55 (1.0295 - 1.0453)	30.0 (1.181)	31932 - X0100
26.65 - 27.05 (1.0492 - 1.0650)	30.5 (1.201)	31932 - X0102
Over 27.15 (1.0689)	31.0 (1.220)	31932 - X0101


Downshift Solenoid

1. Remove downshift solenoid and O-ring.
Catch oil dropping out of the hole.



SAT516

2. Check to verify that downshift solenoid is operating properly. If faulty, replace it with a new one.




SAT517

ON-VEHICLE SERVICE

Kitckdown Switch Adjustment

Wiring Diagram




- L** : L.H. drive models
- R** : R.H. drive models
- E** : For Europe
- C** : Except for Europe
- RN** : R.H. drive models equipped with needle meter
- RD** : R.H. drive models equipped with digital meter

ON-VEHICLE SERVICE

Kickdown Switch Adjustment (Cont'd)

When the pedal is fully depressed, a click can be heard just before the pedal bottoms out. If the click is not heard, loosen the locknut and extend the switch until the pedal lever makes contact with the switch and the switch clicks.




Do not allow the switch to make contact too soon. This would cause the transmission to downshift on part throttle.

DIAGNOSIS:

Switch can be heard clicking, and the transmission still does not kickdown:


Check the continuity of the switch. Also check for available current.

The vehicle upshifts at approximately 55 (1st to 2nd) and 90 km/h (2nd to 3rd) (34 and 56 MPH) only: The kickdown switch may be internally shorted. (When the switch is shorted, there is continuity through the switch in any position).



ON-VEHICLE SERVICE

Overdrive Control System




ON-VEHICLE SERVICE

Overdrive Control System (Cont'd)

O.D. CONTROL SWITCH

Inspection



O.D. control switch


	OFF	ON
1	<input type="radio"/>	
2	<input type="radio"/>	
3	<input type="radio"/>	<input type="radio"/>
4	<input type="radio"/>	<input type="radio"/>

SAT962

ZIEOOK
SUPPLEMENT II
AT-3

O.D. CANCEL SOLENOID

Location




SAT619

ZIEOOK SUPPLEMENT II
AT-3

Inspection

Confirm that clicking sound is heard when power is applied.




SAT620

1387A8

REMOVAL AND INSTALLATION

Removal

Remove bolts securing torque converter to drive plate.



Remove those bolts turning crankshaft. Before removing torque converter, inscribe matching marks on two parts so that they may be replaced in their original positions during assembly.


Plug up openings such as oil charging pipe, etc.

CAUTION:

Be careful when dismounting transmission not to damage any adjacent parts.

Installation

- Drive plate runout
Maximum allowable runout:
0.5 mm (0.020 in)




SAT718

If this runout is out of allowance, replace drive plate and ring gear.

- When connecting torque converter to transmission, measure distance "A" to be certain that they are correctly assembled.

Distance "A":

More than 35 mm (1.38 in)




SAT615

- Install converter to drive plate.
 - a. Align matching marks painted across both parts during disassembly.
 - b. Before installing torque converter securing bolts, apply locking sealer to threads of bolts.
- After converter is installed, rotate crankshaft several turns and check to be sure that transmission rotates freely without binding.

REMOVAL AND INSTALLATION

Installation (Cont'd)

- Check inhibitor switch for operation.
- Check fluid level in transmission.
- Move selector lever through all positions to be sure that transmission operates correctly. With parking brake applied, rotate engine at idling. Move selector lever through "N" to "D", to "2", to "1" and to "R". A slight shock should be felt by hand gripping selector each time transmission is shifted.
- Check to be sure that line pressure is correct. To do this, refer to Line Pressure Test.
- Perform stall test.



Remove bolts securing torque converter to drive plate.




Remove those bolts turning crankshaft. Before removing torque converter, scribe matching marks on two parts so that they may be replaced in their original positions during assembly.

Plug up openings such as oil charging pipe, etc.

CAUTION:
Take care when dismounting transmission not to strike any adjacent parts.

If this runout is out of allowance, replace drive plate and ring gear.


When connecting torque converter to transmission, measure distance "A" to be certain that they are correctly assembled.



- Install converter to drive plate.
- Align matching marks painted across both parts during disassembly.
- Before installing torque converter securing bolts, apply locking sealer to threads of bolts.
- After converter is installed, rotate crankshaft several turns and check to be sure that transmission rotates freely without binding.


ASSEMBLY

Air check point



SAT586

37. Check that parking pawl, pin, spring and washer are assembled correctly.




SAT739

38. Install rear extension.

39. Install control valve assembly. Be sure manual valve is in alignment with selector pin. Tighten control valve body attaching bolts.


Securing bolt comes in three different lengths.



- 1 40 mm (1.57 in)
- 2 35 mm (1.38 in)
- 3 25 mm (0.98 in)

After installing control valve to transmission case, make sure that control lever can be moved to all positions.

40. Before installing vacuum diaphragm valve, measure depth of hole in which it is inserted. This measurement determines correct rod length to ensure proper performance.




SAT078

ASSEMBLY

Vacuum diaphragm rod selection

Measured depth "L" mm (in)	Rod length mm (in)	Part number
Under 25.55 (1.0059)	29.0 (1.142)	31932-X0103
25.65 - 26.05 (1.0098 - 1.0256)	29.5 (1.161)	31932-X0104
26.15 - 26.55 (1.0295 - 1.0453)	30.0 (1.181)	31932-X0100
26.65 - 27.05 (1.0492 - 1.0650)	30.5 (1.201)	31932-X0102
Over 27.15 (1.0689)	31.0 (1.220)	31932-X0101


41. Install vacuum diaphragm.



SAT079


Make sure that vacuum diaphragm rod does not interfere with side plate of control valve.

42. Install downshift solenoid, O.D. cancel solenoid and O.D. indicator switch.



SAT587

43. Install inhibitor switch. Check for proper operation in each range using a circuit tester. Refer to On-vehicle Service.




SAT082

44. Before installing oil pan, check parking pawl engagement.


45. Install oil pan with new gasket.

46. Install governor tube.



SAT521

4. Pour approx. 2-liters (1-3/4 Imp qt) of A.T.F. into converter housing.



SAT518

5. Install torque converter to converter housing. Be careful not to scratch front oil seal.

"R" RANGE

1. Manually shift the control lever from "P" to "R" and note shift quality.
2. Drive the vehicle in reverse long enough to detect slippage or other abnormalities.

"N" RANGE

1. Manually shift the control lever from "R" and "D" to "N" and note quality.
2. Release parking brake with control lever in "N" range. Lightly depress accelerator pedal to make sure vehicle does not move. (When vehicle is new or soon after clutches have been replaced, vehicle may move slightly. This is not a problem.)

"D" RANGE

1. Manually shift the gear selector from "N" to "D" range, and note shift quality.

(Prior to Road Testing)


1. Raise vehicle.
2. Clean area suspected of leaking.
3. Start engine, apply foot brake, place control lever in drive, and wait a few minutes.
4. Stop engine.
5. Check for fresh leakage.

FLUID CONDITION

- Examine the A.T.F. and note its color, texture, and odor.
1. Dark or black fluid is a sign of oxidation.
 2. Milky or pink fluid is a sign of water contamination.
 3. Varnished fluid, light to dark brown and tacky: Oxidation.
- "1" RANGE**
1. While vehicle is being driven in "1" range, release accelerator pedal to make sure engine brake acts as a brake.
 2. Shift control lever to "D" or "2" range and allow vehicle to run at 20 to 30 km/h (12 to 19 MPH). Then, shift control lever to "1" range to make sure the downshift to 1st gear is made.


TROUBLE-SHOOTING AND DIAGNOSES

L4N71B Electrical System/Schematic (For Europe)



TROUBLE-SHOOTING AND DIAGNOSES

L4N71B Electrical System/Wiring Diagram (For Europe)




SAT967

TROUBLE-SHOOTING AND DIAGNOSES

L4N71B Electrical System/ Wiring Diagram (For Europe) (Cont'd)

LOCATION OF 3RD AND O.D. CONTROL UNIT AND KICKDOWN CONTROL UNIT

Rear compartment R.H.




SAT968

TROUBLE-SHOOTING AND DIAGNOSES

Inspection of 3rd and O.D. Control Unit (For Europe)

Check voltage between No. 5 terminal (Ground) and each terminal in the following table.




SAT923

(Lock-up control unit harness connector as seen from front)

Note: Terminal Nos. 3, 6 and 10 are not used.

Check lock-up control unit with harness connector connected.



SAT905


Terminal No.	Checking input/output signal	Checking method	Judgment standard
1	Power source	Make ground connection.	12V at all times while ignition switch is turned ON.
2	O.D. cancel solenoid	Connect tester to terminals 2 and 5. Measure while to operating O.D. control switch.	0V if turned on. 12V if turned off.
3	—	—	—
4	Throttle sensor (ground)	—	—
5	Ground	—	—
6	—	—	—
7	Vehicle speed sensor	Connect tester to terminals 7 and 5. Check voltage variation while running vehicle over 1 m (3 ft) at very low speed.	Voltage must vary from less than 1V to more than 5V.
8	Throttle sensor (power source)	Connect tester to terminals 8 and 4.	8 - 10V at all times.
9	Throttle sensor	Connect tester to terminals 9 and 4. Measure while operating accelerator pedal.	Full-close throttle: approx. 0.7V Full-open throttle: approx. 7V
10	—	—	—

ZIE ook SUPPLEMENT II AT-18 en 19

TROUBLE-SHOOTING AND DIAGNOSES

Inspection of Kickdown Control Unit (For Europe)


Check voltage between No. 4 terminal (Ground) and each terminal in the table below while ignition switch is ON.



(Kickdown control unit harness connector as seen from front)

Note: No. 5 terminal is not used.

Check kickdown control unit with harness connector connected.




SAT969

SAT9

Terminal No.	Checking input/output signal	Checking method	Judgment standard
1	Vehicle speed sensor	Connect tester to terminals 1 and 4. Check voltage variation while running vehicle over 1 m (3 ft) at very low speed.	Voltage must vary from less than 1.0V to more than 5.0V.
2	Power source	Connect tester to terminals 2 and 4.	12V at all times.
3	Kickdown switch	Connect tester to terminals 3 and 4. Measure while operating accelerator pedal.	Fully open accelerator: Less than 1.0V Less than fully open: More than 5.0V
4	Ground	—	—
5	—	—	—
6	Downshift solenoid	Connect tester to terminals 6 and 4. Measure while operating accelerator pedal.	Fully open accelerator: Less than 1.0V Less than fully open: 12V

TROUBLE-SHOOTING AND DIAGNOSES


Pressure Testing



SAT594

PRESSURE

Install pressure gauge to line pressure port.



SAT765

Warm up engine until engine oil and A.T.F. reach operating temperatures.

A.T.F. temperature:

50 - 80°C (122 - 176°F)

Set parking brake and block wheels.

Measure line pressure at idle and at stall point while depressing brake pedal fully.

ZIE ook supplement # AT-28

At idling

Range	Line pressure kPa (bar, kg/cm ² , psi)
R	549 - 686 (5.49 - 6.86, 5.6 - 7.0, 80 - 100)
D	314 - 373 (3.14 - 3.73, 3.2 - 3.8, 46 - 54)
2	373 - 932 (3.73 - 9.32, 3.8 - 9.5, 54 - 135)
1	314 - 373 (3.14 - 3.73, 3.2 - 3.8, 46 - 54)

At stall test

1. Start engine and place select lever in "D" range.
 2. Apply foot brake and accelerate to wide-open throttle.
 3. Quickly note the line pressure and immediately release throttle.
 4. Shift select lever to "N".
 5. Cool off A.T.F.
 6. Perform line pressure testing in the same manner as in steps 2 through 6 with select lever in "2", "1" and "R", respectively.
- Do not perform tests for more than five seconds at any shift range.
 - Do not proceed to next "range" test immediately after one "range" test is done. Wait until oil temperature decreases.

Range	Line pressure kPa (bar, kg/cm ² , psi)
R	2,187 - 2,373 (21.87 - 23.73, 22.3 - 24.2, 317 - 344)
D	1,157 - 1,275 (11.57 - 12.75, 11.8 - 13.0, 168 - 185)
2	1,157 - 1,275 (11.57 - 12.75, 11.8 - 13.0, 168 - 185)
1	1,157 - 1,275 (11.57 - 12.75, 11.8 - 13.0, 168 - 185)

TROUBLE-SHOOTING AND DIAGNOSES


Pressure Testing (Cont'd)

Judgment by measuring line pressure

If line pressure does not rise, first check to make sure that vacuum hose is connected properly.

- 1) When line pressure is low at all positions, the problem may be due to:
 - Wear on interior of oil pump
 - Oil leakage at or around oil pump, control valve body, transmission case or governor
 - Sticking pressure regulator valve
 - Sticking pressure modifier valve
- 2) When line pressure is low at a particular position, the problem may be due to the following:
 - If oil leaks at or around forward clutch (rear) or governor, line pressure is low in "D", "2" or "1" range but is normal in "R" range.
 - If oil leaks at or around low and reverse brake circuit, line pressure becomes low in "R" or "P" range but is normal in "D", "2" or "1" range.
- 3) When line pressure is high, pressure regulator valve may have stuck.

Range	Line pressure kPa (bar, kg/cm ² , psi)
R	2.187 - 2.373 (21.87 - 23.73, 22.3 - 24.2, 317 - 344)
D	1.157 - 1.275 (11.57 - 12.75, 11.8 - 13.0, 168 - 185)
2	1.157 - 1.275 (11.57 - 12.75, 11.8 - 13.0, 168 - 185)
1	1.157 - 1.275 (11.57 - 12.75, 11.8 - 13.0, 168 - 185)



Warm up engine until engine oil and A.T.F. reach operating temperatures.
A.T.F. temperature: 50 - 80°C (122 - 176°F)
Set parking brake and block wheels.
Measure line pressure at idle and at stall point while depressing brake pedal fully.